



LIGHT WEIGHT TUBE BENDER

AF98-2009BLK Instructions

WARNING! These instructions must be read and fully understood before use of this tool. Failure to follow these instructions may result in poor performance, vehicle damage, personal injury or death.

A hand tool for precisely bending pipe, especially a little tweak during installation in that hard to get position. For pipe size 1/16 to 1/4 this tool is able to bend tube with tube nut installed.



1. Place tube into the roller using the stop the brace the pipe.



2. Lightly apply pressure rolling the tube around the groove to desired angle.



3. The stop can be moved for a tighter or lesser radius.

